



### DigitalVision™ Timer

No need to guess. Just lift and check! View how long your toast has left until ready, down to the second, on the large easy-to-read display. By using the Lift and Check™ function you can check on your toast without disrupting the toasting. Pop it back down within ten seconds and the timer will start where it left off.

No need to guess. Just lift and check! View how long your toast has left until ready, down to the second, on the large easy-to-read display. By using the Lift and Check™ function you can check on your toast without disrupting the toasting. Pop it back down within ten seconds and the timer will start where it left off.

### Product Benefits & Features



#### XL Toast Capacity

The two extra-wide capacity slots are designed to accommodate everything from largely sliced bread to thickly cut bagels – making toasting easy.

- Roasting settings
- Stop button
- Red Pilot Light - active when toasting
- Removable crumb tray
- Browning control
- Self centering
- Reheat function



#### Breadcrumb tray

Gone are the days of turning your toaster upside down and shaking it to clean out the breadcrumbs. This toaster comes with a smart Breadcrumb tray - simply detach it for a gentle and easy clean.



#### Bun warmer function

Can't fit your buns inside the toaster? No problem. The foldable bun warmer function lets you heat up bread that won't fit inside a toaster. Treat yourself and the ones you love, to a Saturday breakfast with your favorite croissants and breakfast buns.

### Product Specification

Accent Colour	Licorice
Colour	Stainless steel
Height (mm)	202
Width (mm)	313
Depth (mm)	190
Net Weight	1.66
Watt	980
Roasting Settings	6
Cord Length	1